



## Integrating with pagers

To utilize pagers, you will require an Integration Station transmitter plugged into your network router or directly in a wall connection to deliver messages.

As of publication date, JTECH products using this configuration include, but are not limited to, HostConcepts, SmartCall Messenger, DirectSMS, DirectAlert, CloudAlert, FindMe with Arriva.

JTECH strives to ensure most programming is completed prior to shipment; however, some of the items listed below will require the use of a wired USB keyboard to perform. Please ensure that you have one available to proceed if one was not purchased with the equipment.



Your Integration Station transmitter requires a dedicated IP address within your network. To configure the transmitter, you will require the information below, an Ethernet cable, and a free port on your network and router.

**Please contact your IT Administrator to obtain the address information prior to proceeding. If provided prior to shipping, JTECH will configure the transmitter in advance.**

## To configure the transmitter

Company Code: \_\_\_\_\_

Company Token: \_\_\_\_\_

Dedicated IP Address: \_\_\_\_\_ (example: 192.168.001.222)

Gateway Address: \_\_\_\_\_ (example: 192.168.001.001)

Subnet Mask Address: \_\_\_\_\_ (example: 255.255.255.000)

DNS IP Address: \_\_\_\_\_ (example: 008.008.008.008)

1. Press **SETUP**, enter the password **6629** and press **ENTER**, you should see TCPIP SETUP.
2. Press \* **MENU** 1x. The display will say IP ADDRESS; press **ENTER** to edit this field.
3. Enter the 12-digit IP address IT has provided, when entered press **ENTER** to accept.
4. Press **MENU** 1x. The display will say SUBNET MASK; press **ENTER** to edit this field.
5. Press **MENU** 1x. The display will say GATEWAY IP.; press **ENTER** to edit this field.
6. Enter the 12-digit IP address IT has provided, when entered press **ENTER** to accept.
7. Enter the 12-digit IP address IT has provided, when entered press **ENTER** to accept.
8. Press **CANCEL** to exit the menus
9. Connect transmitter to your network router by plugging an Ethernet cable in the available port, then into the transmitter jack labeled LAN CABLE – On the back of the transmitter the light on the transmitter jack should illuminate green when the connection is live

*NOTE: The transmitter will display a small 'T' in the upper right-hand corner when messages are received from the software and broadcast*

If you experience any issues, please contact JTECH for assistance. [wecare@jtech.com](mailto:wecare@jtech.com) or by phone at 1.800.321.6221.