

# TEMPLATE FOR DC90 SERIES DOOR CLOSER TOP JAMB INSTALLATION

MACHINE SCREWS: USE #7 OR 13/64" DRILL AND 1/4-20 TAP

WOOD SCREWS: USE 5/32" PILOT DRILL

SEX NUTS: USE 3/8" DRILL

4 Holes for #14  
All-Purpose or 1/4-20  
Machine Screws.

