



Guide To Powder Coating With ZRC

ZRC MUST BE APPLIED TO CLEAN, DRY, BARE METAL SURFACES!!

- (1) Apply the ZRC and GALVILITE coating to the clean, bare, dry metal surface.**

- (2) Bake the ZRC at the same temperature, and for the same amount of time as you would the powder coating. This prevents pinholes from forming as a result of solvent evaporation which occurs as the product cures.**

- (3) Allow the ZRC to cool to room temperature.**

- (4) After allowing ZRC to cure at least 12 hours at room temperature, apply the powder coating and follow the specified powder-coating procedure for applying and heating etc.**

**Please call our toll-free number 1-800-831-3275
to place an order or speak with a technical representative**


(800) 831-3275
145 Enterprise Dr., Marshfield, MA 02050
Tel: (781) 319-0400
Fax: (781) 319-0404
Web: www.zrcworldwide.com
E-mail: info@zrcworldwide.com

To the best of our knowledge the technical data contained herein is true and accurate at the date of issuance and is subject to change without prior notice. User must contact ZRC WORLDWIDE to verify correctness before specifying or ordering. No guarantee of accuracy is given or implied. We guarantee our products to conform to ZRC WORLDWIDE quality control. We assume no responsibility for coverage, performance, or injuries resulting from use. Liability, if any, is limited to replacement of products. Prices and cost data, if shown, are subject to change without prior notice. NO OTHER WARRANTY OR GUARANTEE OF ANY KIND is made by ZRC WORLDWIDE, EXPRESS OR IMPLIED, STATUTORY, BY OPERATION OF LAW, OR OTHERWISE, INCLUDING MERCHANTABILITY AND FITNESS FOR A PARTICULAR PURPOSE.