

genuine spare
parts



X-ECO

4X160W LED
6X160W LED

PAGE 1: FLOODLIGHT 150W
PAGE 2: FLOODLIGHT 160W
PAGE 3: MAST
PAGE 4: BASE
PAGE 5: CANOPY
PAGE 6: TOWBAR, AXLE & WHEEL
PAGE 7: ENGINE
PAGE 8: CONTROL PANEL
PAGE 9: TRIME UK CONTACT LIST




TRIME

Lighting Tower Specialist

Review Date: 31/03/2022


150W FLOODLIGHT ASSEMBLY



POS.	CODE	DESCRIPTION
1	AS000_E006_001	JUNCTION BOX
2	AC000_E018_008	PG11 WIRE HOLDER
3	AC000_E018_002	PG21 WIRE HOLDER
4	LED06_C000_01	CENTRAL SUPPORT
5	AC000_E018_018	CLAMP WITH RUBBER
6	AC000_M038_007	CABLE CLIP
7	LED06_C000_012	FRONT COVER
8	PFM08_C000_071	WHITE PLATE
9	PFM08_C000_070	LOGO PLATE
10	PFM08_C000_072	RED PLATE
11	AC000_M038_017	SPACER SCREW
12	AS000_M023_001	SPACER
13	AC000_M000_007	HANDLE
14	LED06_C000_07	HANDLE SUPPORT
15	AC000_E026_005	FLOODLIGHT
16	LED06_C000_09ZN	FLOODLIGHT SUPPORT
17	LED06_C000_04	REAR COVER
18	AC000_E016_002	LIGHT SENSOR
19	LED06_C000_08	JUNCTION BOX COVER
20	AC000_E006_002	ELECTRICAL CLAMP


Part number
X-ECOFLEXREPAIRKIT
Part description
CABLE REPAIR KIT
Additional information


160W FLOODLIGHT ASSEMBLY




N.	CODE	DESCRIPTION
1	AS000_E006_001	JUNCTION BOX
2	AC000_E018_008	PG11 WIRE HOLDER
3	AC000_E018_002	PG21 WIRE HOLDER
4	AC000_P037_010	CAP
5	PFI08_C031_069	CENTERING PLATE
6	AC000_E018_018	CLAMP WITH RUBBER
7	AC000_M038_007	CABLE CLIP
8	LED06_C000_080	CENTRAL SUPPORT
9	PFM08_C000_071	WHITE PLATE
10	PFM08_C000_070	LOGO PLATE
11	PFM08_C000_072	RED PLATE
12	LED04_C000_101ZN	FLOODLIGHT LOWER / CENTRAL BRACKET
13	AC000_E026_087	FLOODLIGHT
14	AC000_M000_076	HANDLE
15	LED06_C000_081ZN	FLOODLIGHT UPPER BRACKET
16	AS000_M023_001	SPACER
17	AC000_E016_005	LIGHT SENSOR ELEMENT
18	LED06_C000_070	REAR COVER
19	AC000_E006_002	ELECTRICAL CLAMP

Part number
X-ECOFLEXREPAIRKIT
Part description
CABLE REPAIR KIT
Additional information


Part number	Part description	Additional information
AS-K4TAF1/P1	HYDRAULIC PRESSURE SWITCH	
X-ECO-ELECTROVALVE	COMPELTE HYDRAULIC ELECTROVALVE	INDIVIDUAL PARTS AVAILABLE

N.	CODE	DESCRIPTION
1	PFI08_C031_019ZN	MAST POSITIONING PLATE, LEFT
2	AC000_M038_007	CLAMP WITH RUBBER
3	AS000_M000_029	SCREW
4	XRENT_C000_011	MAST SUPPORT
5	AS000_M023_026	HYDRAULIC PIPE PIN
6	AC000_G025_001	HYDRAULIC PIPE KIT
7	AS000_I025_001	HYDRAULIC PIPE
8	PFI08_C031_001ZN	1° SECTION MAST
9	PFI08_C031_024	SPACER
10	PFI08_C031_015	DRAW FLANGE
11	PFI08_C031_018ZN	MAST POSITIONING PLATE, RIGHT
12	AC000_M021_002	PULLEY D.60
13	AC000_M021_008	PULLEY D.63
14	AC000_M021_005	STEEL ROPE L.1460mm
15	AC000_M021_012	STEEL ROPE L.1440mm
16	AC000_M021_004	STEEL ROPE L.1440mm
17	AC000_M021_006	STEEL ROPE L.1415mm
18	AC000_M021_007	STEEL ROPE L.1385mm
19	AS000_M000_005	MAST ANGLE GUIDE
20	PFI08_C031_012ZN	MAST ANGLE GUIDE REINFORCEMENT
21	PFI08_C031_008ZN	8° SECTION MAST
22	PFI08_C031_007ZN	7° SECTION MAST
23	PFI08_C031_006ZN	6° SECTION MAST
24	PFI08_C031_005ZN	5° SECTION MAST
25	PFI08_C031_004ZN	4° SECTION MAST
26	PFI08_C031_003ZN	3° SECTION MAST
27	PFI08_C031_002ZN	2° SECTION MAST
28	PFM07_C000_019	CENTERING PIN CLAMP(OPTION)
29	PFI08_C031_017	CENTERING PIN SUPPORT (OPTION)
30	PFM07_C000_014	CENTERING PIN (OPTION)
31	PFI08_C031_029	AIR BUBBLE LEVEL PROTECTION (OPTION)
32	AC000_M016_002	AIR BUBBLE LEVEL
33	PFI08_C031_009	COILED CABLE PROTECTION
34	AC000_P037_001	POMELLO
35	PFM08_C000_047	COILED CABLE LOCK
36	AC000_E006_016	COILED CABLE




Part number	Part description	Additional information
AC000_M000_061	STABILISER CAP COVER	

POS.	CODE	DESCRIPTION
1	XECOK2_C006_049	POWER SUPPLIES SUPPORT
2	AC000_E006_004	4 POLES CLAMP
3	AC000_E006_002	2 POLES CLAMP
4	AC000_M000_081	DRAIN CAP
5	XECOK2_C003_200	STABILIZER
6	XECOK2_C000_226	FRAME FOR FORKLIFT
7	XECOK2_R008_190	RUBBER PROTECTION
8	XECOK2_C000_119ZN	RIGHT STABILIZER BEAM
9	XRENT_C000_037	ANTIROTATION PLATE
10	AC000_M038_007	RUBBERED CLAMP
11	XECOK2_C008_036	MAIN BASE STRUCTURE FRONT COVER
12	XECOK2_C000_117ZN	STABILIZER LOCK
13	XECOK2_R008_191	RUBBER PROTECTION
14	XECOK2_C000_120ZN	LEFT STABILIZER BEAM
15	AC000_M038_026	NUT
16	AC000_M000_077	PIN LOCK WITH SPRING
17	AC000_M000_086	CLOSING LOCK PIN
18	XECOK2_C004_128	MAIN BASE STRUCTURE
19	XECOK2_C006_111	CONTROL PANEL SUPPORT
20	XECOK2_C000_097	LEFT STABILIZER SUPPORT
21	XECOK2_C000_084	HYDRAULIC UNIT SUPPORT
22	AC000_E000_027	BATTERY
23	TF8K1_C000_0014	BATTERY LOCK
24	AC000_M000_028	FUEL TANK CAP
25	AC000_E006_025	FUEL LEVEL TRANSMITTER
26	XECOK2_C005_149	FUEL TANK PLATE
27	XECOK_AS05_009	GASKET
28	XECOK2_C004_034	MAIN BASE STRUCTURE REAR COVER
29	XECOK2_C005_235	FUEL TANK
30	AC000_M000_062	STABILIZER SPRING
31	XECOK2_C000_095	RIGHT STABILIZER SUPPORT
32	XECOK2_C000_096	STABILIZER LOCK
33	XECOK2_C003_093	STABILIZER
34	AC000_E018_017	CURVED CONNECTOR
35	AC000_E018_014	CURVED CONNECTOR NUT
36	AC000_E006_003	JUNCTION BOX
37	AC000_E018_002	CABLE GLAND PG21
38	AC000_E018_009	CABLE GLAND PG16
39	XECOK2_C006_068	JUNCTION BOX SUPPORT
40	AC000_E026_006	POWER SUPPLY



N.	CODE	DESCRIPTION
1	XECOK2_C035_046	MUFFLER EXTENSION
2	XECOK2_M009_161	DOOR RETENTION ROPE
3	AC000_M000_009	DOOR HINGE
4	XECOK2_C007_046	FRONT PANEL
5	AC000_M000_005	HANDLE
6	AC000_M038_041	SPACER
7	XECO_AS009_058	PLASTIC COVER
8	XRENT_C008_044	AIR INLET GRID
9	AC000_M038_009	CLAMP
10	AC000_M001_007	MUFFLER EXTENSION GASKET
11	XECOK2_C008_132	OFFSIDE DOOR
12	PFI08_C031_013	ROTATIONAL SLIDING PLATE
13	PFI08_C031_014ZN	ROTATIONAL SLIDING PLATE REINFORCEMENT
14	XECOK2_C000_050	MAST ROTATION GUIDE PLATE
15	XECOK2_S010_185B	APPROBATION PLATE
16	XECOK2_C036_386ZN	LIFTING EYE
17	XECOK_C035_045	MUFFLER
18	AC000_M000_080	RAIN COVER
19	XECOK_C007_032	MUFFLER COVER
20	AC000_M001_035	RADIATOR CAP COVER
21	AS000_M036_083	RADIATOR CAP COVER RETENTION ROPE
22	XECOK2_C007_129	TOP CANOPY
23	AC000_M000_003	CLOSING LOCK PIN
24	XECOK2_C007_113	REAR PLATE
25	XECOK2_C008_225	AIR OUTLET GRID
26	XECOK2_C007_133	REAR OFFSIDE PANEL
27	XECOK2_C007_134	REAR NEARSIDE PANEL
28	XECOK2_S010_277B	DATA PLATE
29	XRENT_C000_040	LOCK CONTRAST
30	AC000_M000_017	DOOR LOCK
31	XECOK2_C008_131	NEARSIDE DOOR

Part number
AC000_M000_137
Part description
DOOR KEY
Additional information
CH503 DOOR KEY USED WITH ITEM 30




N.	CODE	DESCRIPTION
1	XECOK2_C004_069	RIGHT MUDGUARD
2	XECOK2_R008_188	RIGHT MUDGUARD RUBBER
3	AC000_T003_002	AXLE
4	AS000_M000_073	SLIDE PIN
5	XECOK2_C005_055ZN	REAR TIE ROD
6	AC000_T003_003	JOCKEY WHEEL
7	AC000_E050_016	CABLE WITH CONNECTOR
8	XECOK2_C006_197	CONNECTOR SUPPORT
9	XECOK2_C005_186ZN	TIE RODS JUNCTION
10	XECOK2_C005_059_03ZN	FRONT TIE ROD
11	AC000_T003_004	RUDDER
12	AC000_T003_008	HOOK EYE D.40
13	AC000_T003_016	HOOK EYE D.50
14	AC000_T003_007	HOOK BALL
15	XECOK2_C000_098	LIMIT SWITCHES PLATE
16	XECOK2_C001_101ZN	ADAPTATION BUSHING
17	SI000_G006_009	LIMIT SWITCHES

18	XECOK2_C000_100	COVER PLATE
19	XECOK2_C000_099	LIMIT SWITCHES SUPPORT
20	AC000_E050_017	CABLE WITH PLUGS
21	AC000_E000_062	ADAPTER
22	AC000_E013_001	CABLE WITH PLUG
23	AC000_G006_001	JUNCTION BOX
24	XECOK2_R008_189	LEFT MUDGUARD RUBBER
25	AC000_T013_001	WHITE REFLECTER
26	XECOK2_C004_312	REFLECTER SUPPORT
27	AC000_T013_002	ORANGE REFLECTER
28	XECOK2_C004_070	LEFT MUDGUARD
29	AC000_T003_001	WHEEL
30	AC000_E050_086	LIGHTS WIRING
31	XECOK2_C000_238	LIGHTS HOLDER BAR
32	AC000_E013_007 (**)	OFFSIDE SIDE LIGHT
33	AC000_E013_008 (**)	NEAR SIDE SIDE LIGHT

Part number	Part description	Additional information
AC000_T003_001	AL-KO Wheel	175R 13
AC000_T003_046	OMC Wheel	185R 13
1213889	AL-KO Brake shoe kit	Includes retaining springs
OMC-F0035	OMC Brake shoe kit	Includes retaining springs
247282	AL-KO brake cable	2 per unit
OMC-12.082	OMC brake cable	2 per unit
2081670018	Wheel bolts	
OMC-34.418	Wheel bolts	
AC000_E013_027	Led nearside light cluster	
AC000_E013_026	Led offside light cluster	
AC000_E050_253	LED LIGHT CLUSTER CABLE	CABLE FOR 027 & 026

Part number (23)
AC000_G006_006
Part description
JUNCTION BOX
Additional information
(1in -1 out)






PART NUMBER
X-ECOSERVKITZ482E
PART DESCRIPTION
SERVICE KIT FOR Z482-E
ADDITIONAL INFORMATION
OIL, AIR, FUEL AND INLINE FUEL

N.	CODE	DESCRIPTION
1	XECOK2_C001_006	ENGINE REAR RIGHT SUPPORT
2	AC000_G001_001	OIL DRAIN PIPE
3	XECOK2_C001_126	ENGINE / ALTERNATOR SUPPORT
4	XECOK2_C001_123	ENGINE FRONT RIGHT SUPPORT
5	AC000_M024_054	SCHOCK ABSORBER
6	AC000_M033_007	ENGINE Z482
7	AC000_M038_014	ALTERNATOR FIXING SCREW
8	AC000_E034_007	ALTERNATOR

9	AC000_M038_013	ENGINE FIXING SCREW
10	XECOK2_C001_005	ENGINE REAR LEFT SUPPORT
11	XECOK2_C001_124	ENGINE FRONT LEFT SUPPORT
12	AC000_M038_015	ENGINE REAR SUPPORTS SCREW
13	AC000_M038_047	ENGINE FRONT SUPPORTS SCREW
14	PART OF THE SERCIVE KIT	AIR FILTER
15	XE48_C001_002	AIR FILTER SUPPORT
16	K-1980572530	ENGINE BELT

17	XE48_C001_005	RADIATOR TOP SUPPORT
18	XECOK2_C001_224	RADIATOR FRAME
19	AC000_R008_001	GASKET
20	K-1553172402	RADIATOR TANK
21	K-R140151352	ELECTRIC PUMP
22	XECOK2_C001_236	RADIATOR INFERIOR SUPPORT
23	PART OF THE SERCIVE KIT	FUEL PRE-FILTER
24		OIL FILTER
25		FUEL FILTER
26		OIL DRAIN MANUAL PUMP



N	CODE	DESCRIPTION
1	AC000_E000_070	CAPACITOR
2	AC000_E006_054	CONTACTOR SWITCH
3	AC000_E006_063	4 POLES BRIDGE
4	AC000_E006_062	3 POLES BRIDGE
5	AC000_E006_047	CONTACTOR 20A 230V
6	AC000_M038_037	DIN BAR L 200
7	AC000_E017_015	TERMINAL BOARD ELEMENT
8	XECOK2_C019_232	RIGHT STOP
9	AC000_E017_012	TERMINAL BOARD STOP
10	AC000_E012_030	FUSES HOLDER
11	AC000_E012_014	2A FUSE
12	AC000_E012_013	CIRCUIT BREAKER 12A
13	AC000_E000_008	CIRCUIT BREAKERS COVER
14	AC000_E006_057	SELECTOR
15	AC000_E006_042	CONTACT
16	AC000_E006_043	CONTACTS ADAPTER
17	AC000_E006_044	MAST BUTTONS
18	XECOK2_C019_233	LEFT STOP
19	AC000_E014_001	DSE 3110 CONTROL PANEL
20	AC000_E015_005	FUEL LEVEL GAUGE
21	AC000_E006_001	DSE 3110 CONTROL PANEL GASKET
22	XECOK2_S010_315B	INSTRUMENTS SUPPORT
23	AC000_M038_035	EARTHING TERMINAL
24	AC000_E011_010	230V 16A MAINS INLET
25	AC000_E006_051	STOP BUTTON
26	AC000_E011_007	230V 16A POWER OUTLET
27	AC000_E006_056	STOP BUTTON RATING PLATE
28	XECOK2_S010_106B	INSTRUMENTS SUPPORT
29	AC000_E006_043	CONTACTS ADAPTER
30	AC000_E006_052	CONTACT
31	AC000_E012_013	CIRCUIT BREAKER
32	XECOK2_C006_105	BOX
33	AC000_E018_019	CONNECTOR
34	AC000_E000_016	SWITCH
35	AC000_E000_017	SWITCH
36	AC000_E016_002	LIGHT SENSOR
37	AC000_E012_028	13A RCD
38	AC000_G006_004	10 POLES CONNECTOR
39	AC000_E000_071	5 POLES CONNECTOR
40	AC000_E000_041	12V – 70A RELAY
41	AC000_E000_040	12V – 30A RELAY
42	AC000_G006_003	24 POLES CONNECTOR
43	XECOK2_C019_314	MAIN CONTROL BOX
44	AC000_M038_039	DIN BAR L 275
45	AC000_E006_200	BATTERY CHARGER
46	XECOK2_C006_110	INSTRUMENT HOLDER
47	AC000_M038_037	DIN BAR L 200
48	AC000_E012_027	LAMP SWITCH
49	XRENT_C006_069	CIRCUIT BREAKERS FRAME

Part number	Part description	Additional information
SI000_G006_010	EMERGENCY STOP BUTTON INCLUDES ITEMS 25,27,29 & 30	
SI000_G006_006	MAST BUTTON KIT INCLUDES ITEMS 17,16,15	

Part number
AC000_E016_002NEW
Part description
SLIM LIGHT SENSOR RELAY
Additional information
17MM WIDTH 



TRIME

www.trimeuk.com

SPARE PARTS TEAM



Norman Pipe
Operations/Spares Manager
tel. 01480 220 500
mob. 07495 670269
normanpipe@trimeuk.com



Marcus Wilson
Spares Part Sales
tel. 01480 220 500
marcuswilson@trimeuk.com



Wayne Brennan
Technical Support Manager
tel. 01480 220 500
mob. 07494 654373
waynebrennan@trimeuk.com



Sally Gunn
Accounts Administrator
tel. 01480 220 500
mob. 07494 654373
admin@trimeuk.com

SALES TEAM



Emma Cohen
Sales Assistant
tel. 01480 220 500
marketing@trimeuk.com



Mark Taylor
Sales Manager
tel. 01480 220 500
mob. 07539528017
marktaylor@trimeuk.com



Andrew Owen
Sales Manager
tel. 01480 220 500
mob. 07983871870
andrewowen@trimeuk.com



Paul Hay
Managing Director
tel. 01480 220 500
mob. 07836 522223
paulhay@trimeuk.com



Ray Caulfield
CEO
tel. 01480 220 500
mob. 07970140680
raycaulfield@trimeuk.com

