

genuine spare parts



X-ECO

BATTERY M
4x100W LED
6 x100W LED




PAGE 1: FLOODLIGHT
PAGE 2: MAST
PAGE 3: BASE STRUCTURE
PAGE 4: BATTERY PACK
PAGE 5: TOW BAR, AXLE & WHEELS
PAGE 6: CANOPY
PAGE 7: CONTROL PANEL
PAGE 8: TRIME UK CONTACT



TRIME

Lighting Tower Specialist

Review Date: 31/03/2022



N.	CODE	DESCRIPTION
1	PFI08_C031_019ZN	MAST POSITIONING PLATE, LEFT
2	AC000_M038_007	CLAMP WITH RUBBER
3	AS000_M000_029	SCREW
4	PFI08_C031_011	MAST SUPPORT
5	AS000_M023_026ZN	HYDRAULIC PIPE PIN
6	AC000_G025_001	HYDRAULIC PIPE KIT
7	AS000_I025_001	HYDRAULIC PIPE
8	PFI08_C031_001ZN	1° SECTION MAST
9	PFI08_C031_024ZN	SPACER
10	PFI08_C031_015	DRAG FLANGE
11	PFI08_C031_018ZN	MAST POSITIONING PLATE, RIGHT
12	AC000_M021_002	PULLEY D.60
13	AC000_M021_008	PULLEY D.63
14	AC000_M021_005	STEEL ROPE L.1460mm
15	AC000_M021_012	STEEL ROPE L.1440mm
16	AC000_M021_004	STEEL ROPE L.1440mm
17	AC000_M021_006	STEEL ROPE L.1415mm
18	AC000_M021_007	STEEL ROPE L.1385mm
19	AS000_M000_005	MAST ANGLE GUIDE
20	PFI08_C031_012ZN	MAST ANGLE GUIDE REINFORCEMENT
21	PFI08_C031_008ZN	8° SECTION MAST
22	PFI08_C031_007ZN	7° SECTION MAST
23	PFI08_C031_006ZN	6° SECTION MAST
24	PFI08_C031_005ZN	5° SECTION MAST
25	PFI08_C031_004ZN	4° SECTION MAST
26	PFI08_C031_003ZN	3° SECTION MAST
27	PFI08_C031_002ZN	2° SECTION MAST
28	PFM07_C000_019	CENTERING PIN CLAMP
29	PFI08_C031_017	CENTERING PIN SUPPORT
30	PFM07_C000_014	CENTERING PIN
31	PFI08_C031_029	AIR BUBBLE LEVEL PROTECTION
32	AC000_M016_002	AIR BUBBLE LEVEL
33	PFI08_C031_009ZN	COILED CABLE PROTECTION
34	AC000_P037_001	RUBBER HANDLE
35	PFM08_C000_047	COILED CABLE LOCK
36	AC000_E006_016	COILED CABLE




Hydraulic Electrovalve
Completa

X-ECO ELECTROVALVE



Hydraulic Pressure
Switch


AS-K4TAF1/P1




N.	CODE	DESCRIPTION
1	XECOK2_C006_049	POWER SUPPLIES SUPPORT
2	XECOK2_C006_068	JUNCTION BOX SUPPORT
3	AC000_E006_002	2 POLES CLAMP
4	AC000_M000_081	DRAIN CAP
5	XECOK2_C003_200	STABILIZER
6	XECOK2_C000_226	FRAME FOR FORKLIFT
7	XECOK2_R008_190	RUBBER PROTECTION
8	XECOK2_C000_119ZN	NEAR SIDE STABILIZER BEAM
9	AC000_M038_007	RUBBERED CLAMP
10	XECOK2_C008_036	MAIN BASE FRONT COVER
11	XECOK2_C000_117ZN	STABILIZER LOCK
12	XECOK2_R008_191	RUBBER PROTECTION
13	XECOK2_C000_120ZN	OFFSIDE STABILIZER BEAM
14	AC000_M038_026	NUT
15	AC000_M000_077	PIN LOCK WITH SPRING
16	AC000_M000_086	CLOSING LOCK PIN
17	X BA_C004_094	MAIN BASE STRUCTURE
20	XECOK2_C000_097	OFFSIDE STABILIZER SUPPORT
21	XECOK2_C004_034	MAIN BASE REAR COVER
23	XECOK2_C000_095	NEAR SIDE STABILIZER SUPPORT
24	XECOK2_C000_096	STABILIZER LOCK
25	AC000_E018_017	CURVED CONNECTOR
26	AC000_E018_014	CURVED CONNECTOR NUT
27	AC000_E006_005	JUNCTION BOX
28	AC000_E018_002	CABLE GLAND PG21
29	X BA_C000_095	HYDRAULIC UNIT SUPPORT
30	AS000_I000_020	HYDRAULIC UNIT



N.	CODE	DESCRIPTION
1	X-BA_C006_079	BATTERY PACK SUPPORT
2	AC000_E000_021	BATTERY
3	X-BA_C004_087	BATTERY CHARGER HOUSING
4	AC000_E000_023A	BATTERY CHARGER
5	X-BA_C004_088	BATTERY CHARGER COVER
6	AC000_E000_057	TRANSPARENT COVER
7	X-BA_C006_080	BATTERY PACK UPPER PROTECTION
8	X-BA_C006_081	BATTERY PACK UPPER PROTECTION
9	AC000_E011_019	BATTERY CONNECTOR
10	AC000_E006_126	FUSE HOLDER
11	AC000_E012_056	40A FUSE
12	AC000_E011_015	BATTERY CONNECTOR
13	X-BA_C006_060	BATTERY CONNECTIONS COVER
14	X-BA_C006_059	BATTERY CONNECTIONS SUPPORT
15	X-BA_C006_076	BATTERY CONNECTIONS PLATE
16	X-BA_C006_078	BATTERY PACK LATERAL COVER
17	X-BA_C006_120	BATTERY PACK SUPPORT






N.	CODE	DESCRIPTION
1	XECOK2_C004_069	RIGHT MUDGUARD
2	XECOK2_R008_188	RIGHT MUDGUARD RUBBER
3	AC000_T003_002	AXLE
4	AS000_M000_073	SLIDE PIN
5	XECOK2_C005_055ZN	REAR TIE ROD
6	AC000_T003_003	JOCKEY WHEEL
7	AC000_E050_016	CABLE WITH CONNECTOR
8	XECOK2_C006_197	CONNECTOR SUPPORT
9	XECOK2_C005_186ZN	TIE RODS JUNCTION
10	XECOK2_C005_059_03ZN	FRONT TIE ROD
11	AC000_T003_004	RUDDER
12	AC000_T003_008	HOOK EYE D.40
13	AC000_T003_016	HOOK EYE D.50
14	AC000_T003_007	HOOK BALL
15	XECOK2_C000_098	LIMIT SWITCHES PLATE
16	XECOK2_C001_101ZN	ADAPTATION BUSHING
17	SI000_G006_009	LIMIT SWITCHES
18	XECOK2_C000_100	COVER PLATE

19	XECOK2_C000_099	LIMIT SWITCHES SUPPORT
20	AC000_E050_017	CABLE WITH PLUGS
21	AC000_E000_062	ADAPTER
22	AC000_E013_001	CABLE WITH PLUG
23	ACC00_G006_001	JUNCTION BOX
24	XECOK2_R008_189	MUDGUARD RUBBER
25	AC000_T013_001	WHITE REFLECTOR
26	XECOK2_C004_312	REFLECTOR SUPPORT
27	AC000_T013_002	ORANGE REFLECTOR
28	XECOK2_C004_070	OFFSIDE MUDGUARD
29	AC000_T003_001	WHEEL
30	AC000_E050_086	LIGHTS WIRING
31	XECOK2_C000_238	LIGHTS HOLDER BAR
32	AC000_E013_007	OFFSIDE CLUSTER
33	AC000_E013_009	OFFSIDE CLUSTER LENS
34	AC000_E013_008	NEARSIDE CLUSTER
35	AC000_E013_010	NEARSIDE CLUSTER LENS

Part number
AC000_E013_027
Part description
NEARSIDE LED CLUSTER
Additional information
REPLACES 34 & 35


Part number
AC000_E013_026
Part description
OFFSIDE LED CLUSTER
Additional information
REPLACES 32 & 33




N.	CODE	DESCRIPTION
1	XECOK2_M009_161	DOOR RETENTION ROPE
2	AC000_M000_009	DOOR HINGE
3	X_BA_C007_097	FRONT PANEL
4	AC000_M000_005	HANDLE
5	AC000_M038_048	SPACER H 50
6	AC000_P037_007	PLASTIC WASHER
7	XECO_AS009_058	PLASTIC COVER
8	AC000_M038_041	SPACER H 30
9	AS000_G031_083	DOOR RETENTION ROPE
10	XECOK2_C008_041	OFFSIDE DOOR
11	PFI08_C031_013	ROTATIONAL SLIDING PLATE
12	PFI08_C031_014ZN	SLIDING PLATE REINFORCEMENT
13	XECOK2_C000_050ZN	MAST ROTATION GUIDE PLATE
14	XECOK2_C036_386ZN	LIFTING EYE
15	X_BA_S010_104B	APPROBATION PLATE
16	X_BA_C007_096	TOP CANOPY
17	AC000_M000_003	CLOSING LOCK PIN
18	XECOK2_C007_113	REAR PLATE
19	X_BA_C007_063	AIR OUTLET GRID
20	XECOK2_C007_133	REAR OFFSIDE PANEL
21	XECOK2_C007_134	REAR NEARSIDE PANEL
22	X_BA_S010_103B	DATA PLATE
23	XRENT_C000_040	LOCK CONTRAST
24	AC000_M000_017	DOOR LOCK
25	XECOK2_C008_131	NEARSIDE DOOR
26	X_BA_C036_099	LIFTING EYE REINFORCEMENT
27	X_BA_C008_090	TOP COVER
28	AC000_M001_035	COVER
29	X_BA_C007_098	OFFSIDE PANEL

Part number
AC000_M000_137
Part description
DOOR KEY
Additional information
CH503 DOOR KEY USED WITH ITEM 24





N.	CODE	DESCRIPTION
1	X-BA_C019_101	CONTROL PANEL BOX
2	AC000_E006_097	CONTACTOR SWITCH
3	XHY_C006_136	CONTACTOR SWITCH SUPPORT
4	X-BA_C006_089	CIRCUIT BREAKERS SUPPORT
5	AC000_E006_060	TIMER
6	X-BA_C006_024	CIRCUIT BREAKERS FRAME
7	XECOK2_C019_232	RIGHT STOP PLATE
8	AC000_E006_041	SELECTOR
9	AC000_E000_008	CIRCUIT BREAKER PROTECTION
10	XECOK2_C019_233	LEFT STOP PLATE
11	AC000_E006_076	BATTERY CHARGE MONITOR
12	AC000_E006_045	GREEN LAMP
13	X-BA_S010_102B	INSTRUMENTS PLATE
14	XECOK2_C006_105	EXTERNAL CONTROL PANEL BOX
15	AC000_M038_035	EARTHING TERMINAL
16	AC000_E011_010	INLET 230V 16A
17	AC000_E006_051	STOP BUTTON
18	AC000_E006_053	STOP BUTTON RATING PLATE
19	XHY_S010_140B	INSTRUMENTS PLATE
20	AC000_E006_043	CONTACTS SUPPORT
21	AC000_E006_052	STOP BUTTON CONTACT
22	AC000_E018_019	CONNECTOR
23	AC000_E006_046	GREEN LAMP CONTACT
24	AC000_G006_004	10 POLES CONNECTOR
25	AC000_E012_027	16A CIRCUIT BREAKER
26	AC000_E006_042	MAST BUTTONS CONTACT
27	AC000_E006_063	4 WAYS BRIDGE
28	AC000_M038_037	L200 DIN BAR
29	AC000_E006_022	FINAL ELEMENT FOR TERMINAL BOARD
30	AC000_E006_021	CLAMP
31	AC000_E006_024	TERMINAL BOARD COVER
32	AC000_E000_071	5 POLES CONNECTOR
33	AC000_E011_016	SCHUKO SOCKET
34	AC000_E018_016	PG16 CURVED CONNECTOR
35	AC000_E006_044	MAST BUTTONS





TRIME

www.trimeuk.com

SPARE PARTS TEAM



Norman Pipe
Operations/Spares Manager
tel. 01480 220 500
mob. 07495 670269
normanpipe@trimeuk.com



Marcus Wilson
Spares Part Sales
tel. 01480 220 500
marcuswilson@trimeuk.com



Wayne Brennan
Technical Support Manager
tel. 01480 220 500
mob. 07494 654373
waynebrennan@trimeuk.com



Sally Gunn
Accounts Administrator
tel. 01480 220 500
mob. 07494 654373
admin@trimeuk.com

SALES TEAM



Emma Cohen
Sales Assistant
tel. 01480 220 500
marketing@trimeuk.com



Mark Taylor
Sales Manger
tel. 01480 220 500
mob. 07539528017
marktaylor@trimeuk.com



Andrew Owen
Sales Manger
tel. 01480 220 500
mob. 07983871870
andrewowen@trimeuk.com



Paul Hay
Managing Director
tel. 01480 220 500
mob. 07836 522223
paulhay@trimeuk.com



Ray Caulfield
CEO
tel. 01480 220 500
mob. 07970140680
raycaulfield@trimeuk.com

