


TOCA TOUCH TRAINER COMPONENTS



- A** Spiral Hopper Sections
(1 End, 2 Standard)
- B** Center Tube Sections (3)
- C** Telescoping Handle
- D** Power Button
- E** Charging Port
- F** Base Plate
- G** Main Body Cover
- H** Solenoid
- I** Launch Wheel
- J** Launch Wheel Set Screw
- K** Drive Motor Cover
- L** Kill Switch (US/EU 1100 model only)
- M** Power Cord & AC Power Adapter
- N** Serial Number Label
- O** Motor Launch Bracket (Right)
- P** Motor Launch Bracket (Left)
- Q** Scooter Tire
- R** TOCA Ball - (Size 2 -7-9 PSI)
- S** Pressure Gauge
- T** Center Tube Base



TOCA FOOTBALL MAINTENANCE SCHEDULE



COMPONENTS	INSTRUCTIONS
TOCA Balls	CHECK Ball Pressure - 7-9 PSI CLEAN Debris. WIPE with dry/damp cloth. DRY balls well prior to use.
	PURCHASE New TOCA Balls (every 6-12 months)
Spiral Hopper Assembly	CLEAN debris from Spiral Hopper Assembly. WIPE using dry, lint-free towel.
	INSPECT hardware and check for missing hardware. ADJUST fitment if necessary .
Main Body Cover & Drive Motor Cover	CLEAN debris off Main Body Cover and Drive Motor Cover. WIPE down with dry, lint-free towel
	INSPECT hardware and CHECK for missing hardware.
	INSPECT Telescoping Handle. PULL in/out to ensure it is working.
Solenoid	PERFORM "Push Test" (Push Solenoid in and twist). CHECK for grinding sounds or restrictive movement. If yes, APPLY Dry WD-40.
	APPLY small amount of Dry WD-40 to fourth spring. PUSH Solenoid in and twist until grinding/restrictive movement is gone.
	CLEAN excess lubricant.
Launch Wheels	TURN TOUCH TRAINER OFF. CLEAN debris. WIPE Launch Wheels and Launch Wheel Hubs with a dry, lint-free towel.
	CHECK Motor Launch Brackets. WIGGLE Motor Launch Brackets from side-to-side. If loose, CONTACT support. INSPECT visually. CHECK hardware. ENSURE Launch Wheels are at same height.
Power Adapter	CHARGE Touch Trainer completely for 2.5 hours.

Regularly
Weekly
Monthly
Yearly

844.444.TOCA
 support@TOCAfootball.com
 TOCAfootball.com