

ProfileVent®

Metal roofing ridge vents – rolls



- Limited lifetime warranty
- Glue spots prevent slipping during installation
- Fits under any ridge cap
- Fits any pitch 3:12 – 20:12
- One person roll-out installation
- Won't scratch panel finish
- Won't crack, dent or rust during shipping or installation
- Won't clog from airborne dust
- No release paper – no waste
- Net free area is 17 sq. in. per lineal ft.
- Prevents insect infiltration
- Prevents snow infiltration
- Provides proven roof ventilation
- Meets all model building codes
- Packing in English, French and Spanish
- No waste—use leftovers on next job
- Will not support a flame
- Will not degrade due to UV exposure
- Made in U.S.A.





Application


ProfileVent Rolls

New or re-roof on Purlin or wood deck Construction:


Use a 2" opening at the ridge to provide ventilation. On new or re-roof wood deck construction, cut a 2" slot at the ridge (1" each side, start cut 6" from gable ends). On purlin construction position panels to leave a 2" opening.



1 Allow 2" opening at ridge for ventilation. ProfileVent is rolled out along the ridge, gable to gable, about 1/2" to 1" up-slope from the ridge cap edge. The positioning adhesive on most profiles will hold ProfileVent in position and allow for repositioning.



2 ProfileVent can be cut with scissors or utility knife.
Inset: When splicing ProfileVent, make the splice at the center top of the high rib and use caulk or sealant along the splice.



3 Screw through ridge cap and top of each anchor clip. Blind Rivets can be used to anchor the ridge cap when using architectural or standing seam panels.